



shenzhen ecartek technology company ltd  
www.ecartek.com 400-8262518

## KD-MAX MANUAL

### 1 Product Overview

KD-MAX is a professional mutli-functional smart device. It works with Android system, built-in with bluetooth and WIFI module, equipped with 5.0 inch LCD display screen. The user-interface was clear, simple and easily manipulative. Device functions including Frequency Checking, Remote Generating, Remote Clone, Chip Recognition/Edition/Decoding/Clone, Dedicated Chip Generating, Chip Data Acquisition, Car Key Unlock, IC/ID Card Recognition/Clone, Online Program Generating, Battery Voltage Detection, Battery Leakage Detection, Online Updating and so on. It is an essential professional locksmith tool.



1

### 2 Product Functions

01) Master Device	1 pc
02) Data Cable	1 pc
03) Remote Generating Cable	2 pcs
04 Unlocking Cable	1 pc
05) User Manual	1 pc

Note: Please check package parts after open the package, if any part shortage please contact the supplier.

2

### 3 Product Functions

✓ Car Remote Generating	✓ Garage Remote Generating/Clone
✓ Remote Clone	✓ Chip Recognition/ Edition/Decoding/Clone
✓ Dedicated Chip Generating	✓ Remote Battery Leakage Detection
✓ Car Key Unlock	✓ IC/ID Card Recognition/Clone
✓ Frequency Checking	✓ Battery Voltage Detection

3

### 4 Main Performance Parameters

 Battery Capacity 3375mAh	 Normal working hours >8 hours	 Standby Time >7 Days	 Charging Current 1500mA
 Luminance >400nits	 Screen Resolution 1280*720P	 Camera Resolution 51inch	 Screen Dimension 800W

4

### 5 Product Outside View



5



6

### 6 Button Description

- 1.Switch button:**  
When the device is power off, hold the switch button for 2 seconds to start it. When it is power on, hold switch button 2 seconds will see 3 options: Power Off, Restart and Screenshot. When the screen is on, press the switch button once, the device will turn off the screen for standby; When the screen is off, press the switch button once to light up the screen;
- 2.HOME Button:**  
Press the HOME button once to pop up the shortcut button function list, and then press the home key once to exit;
- 3.Compulsory Resetting Button:**  
Insert the card taking pin to the hole on the bottom left to reset the device compulsorily.

7

### 7 Hardware Ports Description

- 1.TYPE-C Charging Port**  
Please use 4.5-5.5V/2A charging plug to connect TYPE-C cable to charge. When charging is finished, the device will stop charging automatically to protect the battery.
- 2.PS2 Burning Port**  
1)Insert remote generate cable(6P cable) to generate remote;  
2)Insert unlock cable to unlock remotes;  
3)Insert unlock cable, enter the Battery Leakage Detection mode, connect the red cable to the positive side on the remote board, and black one to negative side to detect battery leakage. ( Remove the remote battery first)
- 3.Voltage Detection Interface**  
Insert battery to the CR port( Pay attention to the positive and negative poles), enter Voltage Detection mode to detect battery voltage.  
( See the picture 2 on the right)



8

### 8 Safety Precautions

- Please keep it from water, dust and falling;
- Do not store or use the device in the environment of high temperature, high humidity, flammability, explosion and strong magnetic field;
- Do not use a charger with mismatched specifications to charge the device;
- Do not disassemble the device or change the internal parts of the device without permission, otherwise you will bear the adverse consequences;
- Please protect the display screen, camera and other key components to prevent damage caused by sharp objects.

9

### 9 Warranty and After-sales Instructions

The non-human fault warranty period of the device is two years (one year battery warranty), which is starting by activation by user. During the warranty period, damages which after KEYDIY professionals checking and find not caused by users will be fixed free by KEYDIY company, After warranty period KEYDIY company will recharge according maintenance costs.

**Any of the following circumstances during the warranty period we will not offer free maintenance.**

- 1.Damage to components and circuit boards due to improper use by users or accidental disasters;
- 2.The equipment is damaged due to self disassembly, repair or modification;
- 3.The equipment is damaged due to failure to follow the precautions in the manual;
- 4.The machine is damaged due to collision, falling and improper voltage;
- 5.The equipment shell is worn and dirty due to long-time use;

Statement: The final interpretation right of this manual belongs to Shenzhen Yiche Technology Co., Ltd. Without permission, no individual or organization may copy and disseminate this manual in any situation.

10